



Optional

30	Display panel	显示板	1		
29	Control Box Assembly	控制盒组件	1		
28	Glass Front Plate	玻璃前板	1		
27	Start Capacitor	启动电容	1		
26	Control Box	控制盒	1		
25	Button Assembly	按键组件	1		
24	Key-Press Board	按键板	1		
23	Control Box Cover	控制盒盖	1		
22	Charcoal Filter Assembly Round	活性炭组件圆形	2		
21	Exhaust Pipe Joint	排烟管接头	1		
20	Body Front Plate	箱体前板	1		
19	Switch Bracket	开关支架	1		
18	Key Switch	琴键开关	1		
17	Control Box Cover	控制盒盖	1		
16	Control Box Assembly	控制盒组件	1		
15	Main Wire Harness	线束	1		
14	Rack assembly	机架组件	1		
13	Terminal Box	接线盒	1		
12	Connecting Box Cover	接线盒盖	1		
11	Connecting Board	连接板	1		
10	Power Cord	电源线	1		
9	Decorative Cover	装饰罩	1		
8	Adjustable Decorative Cover	可调装饰罩	1		
7	Decorative Cover Hanging Board	装饰罩挂板	1		
6	Exhaust Pipe	排烟管	1		
5	Hand Board	机体挂板	1		
4	Fan Assembly	风机组件	1		
3	Tub Assembly	箱体组件	1		
2	Lamp	照明灯	2		
1	Filter Scream Assembly	过滤网组件	2		

序号	Name	名称	数量	材料、规格	备注
组合件				佛山市美的厨房电器制造有限公司	
标记	处数	分区	更改文件号	签字	日期
设计			标准化		
校对			审定		
审核			批准		
工艺			日期		
阶段标记			比例		
S   A			1:1		
数量			重量		
第 1 页			共 1 页		

爆炸图

90M21