

EXPLODE VIEW AND PART LIST

THE PART LIST OF CABINET ASSEMBLY (A134 A155 (A103) (A102) (A104) ' A106 (A110) (A152 (A151) A150 (A141) A101 (A120) A100 (A130) (A430) (A440 A140 (A410) A131 (K611) (A133) (A310 A135 (A303) A200 A485 A220 COLD (BLUE) (A276) A201) (A450)

THE EXPLODED VIEW OF CONTROLANEL & DISPENSER ASSEMBLY



THE EXPLODED VIEW OF DRUM & TUB ASSEMBLY



THE EXPLODED VIEW OF DRYER

